Harley Benton

# HB-10G

guitar combo

thomann
MUSIC IS OUR PASSION

user manual

Musikhaus Thomann e.K.
Treppendorf 30
96138 Burgebrach
Germany
Telephone: +49 (0) 9546 9223-0
E-mail: info@thomann.de
Internet: www.thomann.de

23.06.2014, ID: 147165

# Table of contents


1 **General notes** ..... 4
2 **Safety instructions** ..... 6
3 **Features** ..... 10
4 **Installation and starting up** ..... 11
5 **Connections and operating elements** ..... 12
6 **Technical specifications** ..... 16
7 **Plug and connection assignment** ..... 17
8 **Protecting the environment** ..... 19

# 1 General notes

This user manual contains important information on safe operation of the device. Read and follow all safety notes and all instructions. Save this manual for future reference. Make sure that it is available to all persons using this device. If you sell the device, include the manual for the next owner.

Our products are subject to a process of continuous development. We therefore reserve the right to make changes without notice.

**Symbols and signal words**

This section provides an overview of the symbols and signal words used in this user manual.

| Signal word | Meaning |
|---|---|
| **DANGER!** | This combination of symbol and signal word indicates an immediate dangerous situation that will result in death or serious injury if it is not avoided. |
| **CAUTION!** | This combination of symbol and signal word indicates a possible dangerous situation that can result in minor injury if it is not avoided. |
| **NOTICE!** | This combination of symbol and signal word indicates a possible dangerous situation that can result in material and environmental damage if it is not avoided. |

| Warning signs | Type of danger |
|---|---|
| | Warning – high-voltage. |
| | Warning – danger zone. |

# 2 Safety instructions

**Intended use**

This device is intended to be used for amplification and playback of signals from musical instruments with electromagnetic pickups. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damages resulting from improper use.

This device may be used only by persons with sufficient physical, sensorial, and intellectual abilities and having corresponding knowledge and experience. Other persons may use this device only if they are supervised or instructed by a person who is responsible for their safety.

**Safety**

**DANGER!**

**Danger for children**

Ensure that plastic bags, packaging, etc. are disposed of properly and are not within reach of babies and young children. Choking hazard!

Ensure that children do not detach any small parts (e.g. knobs or the like) from the unit. They could swallow the pieces and choke!

Never let children unattended use electrical devices.

**DANGER!**

**Electric shock caused by high voltages inside**

Within the device there are areas where high voltages may be present. Never remove any covers.

There are no user-serviceable parts inside.

**DANGER!**

**Electric shock caused by short-circuit**

Do not modify the mains cable or the plug. Failure to do so could result in electric shock/death or fire. If in doubt, seek advice from a registered electrician.

**CAUTION!**

**Possible hearing damage**

The device can produce volume levels that may cause temporary or permanent hearing impairment. Over an extended period of time, even levels that seem to be uncritical can cause hearing damage.

Decrease the volume level immediately if you experience ringing in your ears or hearing impairment. If this is not possible, keep a greater distance or use sufficient ear protectors.

**NOTICE!**

**Risk of fire**

Do not cover the device nor any ventilation slots. Do not place the device near any direct heat source. Keep the device away from naked flames.

**NOTICE!**

**Operating conditions**

This device has been designed for indoor use only. To prevent damage, never expose the device to any liquid or moisture. Avoid direct sunlight, heavy dirt, and strong vibrations.

**NOTICE!**

**Power supply**

Before connecting the device, ensure that the input voltage (AC outlet) matches the voltage rating of the device and that the AC outlet is protected by a residual current circuit breaker. Failure to do so could result in damage to the device and possibly injure the user.

Unplug the device before electrical storms occur and when it is unused for long periods of time to reduce the risk of electric shock or fire.

# 3 Features

Special features of the device

- Output power 10 watt
- 6" speaker
- Overdrive switch
- Aux input
- Headphones output
- Standby function

# 4 Installation and starting up

Unpack and carefully check that there is no transportation damage before using the unit. Keep the equipment packaging. To fully protect the device against vibration, dust and moisture during transportation or storage use the original packaging or your own packaging material suitable for transport or storage, respectively.

Establish all connections as long as the unit is switched off. Use the shortest possible high-quality cables for all connections.

**NOTICE!**

**Possible property damage by magnetic fields**

Loudspeakers produce a static magnetic field. Therefore, maintain an appropriate distance to devices that can be adversely affected or damaged by an external magnetic field.

# 5 Connections and operating elements

**Front panel**



| | |
|---|---|
| 1 | *[INPUT]*<br>1/4" phone socket to connect your instrument. |
| 2 | *[CHANNEL SELECT]*<br>Switch to toggle between clean and overdrive channel. |
| 3 | *[GAIN]*<br>Control to adjust the signals preamp gain. |
| 4 | *[BASS]*<br>Control to adjust the bass. |
| 5 | *[MIDDLE]*<br>Control to adjust the mids. |
| 6 | *[TREBLE]*<br>Control to adjust the treble. |
| 7 | *[VOLUME]*<br>Volume control. |

| | |
|---|---|
| 8 | Headphones output (3.5 mm mini phone socket).<br>When you connect headphones, the internal speaker is automatically muted. |
| 9 | Aux input for connecting an MP3 or CD player (3.5 mm mini phone socket). |
| 10 | Standby indicator<br>This LED lights red during normal operation. If there is no signal input at the *[INPUT]* jack for 30 minutes, the device will automatically enter standby mode. As soon as the *[INPUT]* jack receives a signal again, the device switches back to normal mode. |
| 11 | *[POWER]*<br>Mains switch. Turns the device on and off. |

**Rear panel**


12
CAUTION
AVIS: RISQUE DE CHOC ELECTRIQUE - NE PAS OUVRIR.
TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK DO NOT EXPOSE THIS EQUIPMENT TO RAIN OR MOISTURE.
POWER SOURCE:
~100VAC 50/60Hz
~120VAC 50/60Hz
~230VAC 50/60Hz
~240VAC 50/60Hz
MAXIMUM POWER CONSUMPTION
20 WATTS ~50/60Hz
WARNING - TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK. DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.
CAUTION - FOR CONTINUED PROTECTION AGAINST RISK OF FIRE REPLACE ONLY WITH SAME TYPE AND RATED FUSE.
CAUTION - TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE COVERS. NO USER SERVICABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED PERSONNEL ONLY.
WARNING - THIS EQUIPMENT MUST BE EARTHED.
ATTENTION - REMPLACER LE FUSIBLE SEULEMENT PAR LE MEME TYPE ET LE MEME CALIBRE.
3085672
CONFORMS TO UL STD. 60065
CERTIFIED TO CAN/CSA STD. C22.2 NO.60065:03
MADE IN CHINA
SERIAL NO:

| | |
|---|---|
| 12 | Power cord. |

# 6 Technical specifications

| | |
|---|---|
| Output power | 12 W (RMS) @ 4 Ω (Overdrive)<br>8 W (RMS) @ 4 Ω (Clean-Sound) |
| Speakers | 1 × 6" speaker |
| Frequency response | 80 Hz to 10 kHz |
| Input impedance | 220 kΩ |
| THD | 0.5% (Clean-Sound) |
| Signal-to-noise ratio | 75 dB |
| Power consumption | max. 20 W |
| Operating supply voltage | AC 220 – 240 V ~, 50/60 Hz |
| Dimensions (H × W × D) | 280 mm × 275 mm × 150 mm |
| Weight | 4.5 kg |

# 7 Plug and connection assignment

**Introduction**

This chapter will help you select the right cables and plugs to connect your valuable equipment in such a way that a perfect sound experience is ensured.

Please note these advices, because especially in 'Sound & Light' caution is indicated: Even if a plug fits into the socket, an incorrect connection may result in a destroyed power amp, a short circuit or 'just' in poor transmission quality!

**Balanced and unbalanced transmission**

Unbalanced transmission is mainly used in semi-professional environment and in hifi use. Instrument cables with two conductors (one core plus shielding) are typical representatives of the unbalanced transmission. One conductor is ground and shielding while the signal is transmitted through the core.

Unbalanced transmission is susceptible to electromagnetic interference, especially at low levels, such as microphone signals and when using long cables.

In a professional environment, therefore, the balanced transmission is preferred, because this enables an undisturbed transmission of signals over long distances. In addition to the conductors 'Ground' and 'Signal', in a balanced transmission a second core is added. This also transfers the signal, but phase-shifted by 180°.

Since the interference affects both cores equally, by subtracting the phase-shifted signals, the interfering signal is completely neutralized. The result is a pure signal without any noise interference.

**1/4" TS phone plug (mono, unbalanced)**

| | |
|---|---|
| 1 | Signal |
| 2 | Ground, shielding |

**Three-pole 1/8" mini phone jack (stereo, unbalanced)**

| | |
|---|---|
| 1 | Signal (left) |
| 2 | Signal (right) |
| 3 | Ground, shielding |

# 8 Protecting the environment

**Disposal of the packaging material**

For the transport and protective packaging, environmentally friendly materials have been chosen that can be supplied to normal recycling.

Ensure that plastic bags, packaging, etc. are properly disposed of.

Do not just dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the notes and markings on the packaging.

**Disposal of your old device**

This product is subject to the European Waste Electrical and Electronic Equipment Directive (WEEE). Do not dispose with your normal household waste.

Dispose of this device through an approved waste disposal firm or through your local waste facility. When discarding the device, comply with the rules and regulations that apply in your country. If in doubt, consult your local waste disposal facility.